

Operating Instructions

The R2-MiNi has been designed to operate the majority of today's current TV's, satellite and cable boxes.

1 Battery Installation



STEP1 Remove the battery compartment cover on the back of your remote control.

STEP2 Check battery polarity carefully, and install the batteries as shown in the illustration left.

STEP3 Replace battery compartment cover.

2 Programming IR Codes to the R2-MiNi

STEP1 Turn on TV or cable/ satellite box.

STEP2 Press and hold device button (TV or CBL/SAT) on remote for 3 seconds. (Device LED will stay on.)

STEP3 Point the remote towards the device and press CH+ or CH- with single button presses. (The correct IR code is achieved when the device shuts off.)

STEP4 Press the corresponding device button again to save the code. (The device LED will blink twice to confirm that the code is saved.)

3 Reverting Back to TV or CBL/SAT Channel Control

The channel control will default automatically to the CBL/SAT device when programmed with an IR code.

STEP1 Press and hold the CBL/SAT button for 3 seconds. (The CBL/SAT LED will stay on.)

STEP2 Press the VOL + button.

STEP3 Press the CBL/SAT button for cable /satellite channel control or the TV button for TV channel control. (The device LED will blink twice to confirm the change.)

